



USER MANUAL

SERIES J

Wiegand
Custom Watch, LLC.



PRECISION CRAFTED
USER APPROVED

MISSION

ABOUT

Chris Wiegand - President, takes extreme pride in every watch we produce. He is always available to answer questions and help customers.

We take pride in our service. With service points around the globe, you can be assured that for any repair you will have a fast turnaround time, so you can get your watch back on your wrist fast and enjoy it.

LÜM-TEC® takes watch manufacturing and design to a personal level. We freely communicate with our customers through email, phone and on web forums daily. We value our customer's opinions and input. We use customer feedback to improve our products and our business. Our customers are what makes **LÜM-TEC** unique and what separates us from other watch companies.

CONTENTS

Basic Instructions..... 6-10

Miyota OS20..... 12-13

ETA 2893-2 GMT..... 14-15

Miyota OT45..... 16-17

Ronda 515.24H..... 18-19

ETA 2824-2 20-21

Selita SW 200..... 22-23

Sii NH35..... 24-25

CARE AND MAINTENANCE

A maintenance interval of between 5 and 10 years is recommended and is in addition to required battery replacement on quartz models. Never open the watch yourself. If your watch needs repair or adjustment, take or mail it directly to a **LÜM-TEC** authorized service repair center.

NOTE: **LÜM-TEC** assumes responsibility only for service performed at its authorized service centers.

Shock

All **LÜM-TEC** watches have shock-resistant movements, individually tested to meet international standards.

DUST

Dust can enter a watch if the case, crystal or crown is not intact. A small particle is enough to stop the movement. Have your watch repaired promptly if the crystal becomes loose, chipped or cracked, or if there is damage to the case or crown.

Magnetism

The exposure of a timepiece to strong magnetic fields will affect its time-keeping and may cause it to stop. A quartz watch should resume working with its original accuracy when removed from the magnetic field. A mechanical timepiece may require demagnetization before it will operate properly again.

Luminescent Output

Our luminous compound is based on Super LumiNova®. Markings covered with Super LumiNova® will remain clearly visible for the whole night provided that sufficient activation (minimum 5-10 minutes) by sunlight or fluorescent light has occurred. Ambient light is a factor in marker visibility.



Water Resistance

All **LÜM-TEC** watches are tested to meet international standards for water resistance.

To maintain water resistance, periodic maintenance is required. The gaskets and crown which seal the case are subject to wear and deterioration under normal use. These parts should be inspected and replaced as needed each time the watch is opened for service, including battery changes.

CAUTION: **LÜM-TEC** will not be responsible for any damage caused by or related to leakage originating from improper handling or damage to the case, crown, gaskets or crystal.

IMPORTANT: Do not operate the chronograph pushbutton on a chronograph model while the timepiece is under water.

Miyota OS20 Instructions

MODELS B42

FUNCTION

A) DATE SETTING :

To adjust the date, pull the crown to the 2nd position. Rotate the crown counter clockwise to the correct date. * If the date is set between the hours of 9:00 PM and 1:00 AM, the date may not change on the following day. Once finished, push the crown in completely.

B) TIME SETTING:

Pull the crown out to the 3rd position. Turn the crown to set hour and minute hands. When the crown is pushed back to the normal position, small second hand begins to run.

C) CHRONOGRAPH USE:

The chronograph can be started and stopped each time button "A" is pressed. Pressing button "B" resets the chronograph and the chronograph second hand and chronograph minute hand return to zero position.



ETA 2893-2 GMT Instructions

MODELS B4

FUNCTION

A) WINDING

Unscrew the crown until it releases into the 1st position. Turn the crown clockwise to manually wind. The movement will also self wind while worn on the wrist. To achieve a full wind, turn the crown 40 times clockwise for a maximum power reserve. Once finished, push the crown in and screw down completely.

B) SETTING THE DATE

Unscrew the crown and pull to the second position, then turn the crown clockwise to adjust the date. Once finished, push the crown in and screw down completely.

C) SETTING THE TIME

Unscrew the crown and pull to the 3rd position, then turn the crown until the current time is set. To prevent movement damage, move hands only in a clockwise direction. Once finished, push the crown in and screw down completely.

D) SETTING THE GMT

Unscrew the crown and pull to the second position, then turn the crown counter clockwise to adjust the GMT hand. Once finished, push the crown in and screw down completely.



Miyota OT45 Instructions

FUNCTION

A) SETTING THE DATE

Pull the crown out to the 2nd position. Turn the crown counter-clockwise to set the date.

* If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day. After the date has been set, push the crown back to the normal position.

B) SETTING THE TIME

Pull the crown out to the 3rd position. Turn the crown to set hour and minute hands. When the crown is pushed back to the normal position, small second hand begins to run.

MODELS B40



Ronda 515.24H Instructions

MODELS B41

FUNCTION

A) SETTING THE DATE

Unscrew the crown and pull to the 2nd position. Turn the crown clockwise to set the proper date. Once finished, push the crown in and screw down completely.

B) SETTING THE TIME

Unscrew the crown and pull to the 3rd position. Rotate the crown counter clockwise to set the time. Once finished, push the crown in and screw down completely.

C) ADJUSTING THE HOUR HAND

Pull crown to date set position and rotate the crown counter clockwise to desired position.



ETA 2824-2 Instructions

MODELS M80, M81

FUNCTION

A) SETTING THE DATE

Unscrew the crown and pull to the 2nd position. Turn the crown clockwise to set the proper date. Once finished, push the crown in and screw down completely.

B) SETTING THE TIME

Unscrew the crown and pull to the 3rd position. Rotate the crown counter clockwise to set the time. Once finished, push the crown in and screw down completely.

C) MANUAL WINDING

Set the crown to the 1st position and rotate the crown clockwise.



Selita SW 200 Instructions

MODELS X1, X2, X3

FUNCTION

A) SETTING THE DATE

Unscrew the crown and pull to the 2nd position. Turn the crown clockwise to set the proper date. Once finished, push the crown in and screw down completely.

B) SETTING THE TIME

Unscrew the crown and pull to the 3rd position. Rotate the crown counter clockwise to set the time. Once finished, push the crown in and screw down completely.

C) MANUAL WINDING

Set the crown to the 1st position and rotate the crown clockwise.



Sii NH35 Instructions

FUNCTION

A) SETTING THE TIME

Second position, time setting clockwise and counterclockwise.

B) MANUAL WINDING

Screwed down position, clockwise = Manual Winding / Counterclockwise = Nothing

MODELS C5, C6, C7



CONTACT

Wiegand Custom Watch, LLC.
7245B Industrial Park Blvd
Mentor, OH 44060
T. (440)-951-1296
1-877-2LUMTEC

INTERNET

www.Lum-Tec.com
info@lum-tec.com
service@lum-tec.com

SOCIAL NETWORK

Facebook - [Facebook.com/lumtecllc](https://www.facebook.com/lumtecllc)
Instagram @LumTecWatches
Twitter @LumTecWatches

